

Neptune E-Coder Water Meter



The City of Warman staff will read your meter for billing purposes, but **should you wish to monitor your own consumption**, here's how:

- Shine a flashlight over the flashlight icon (located on the register) to turn the LCD display on
- Take a reading at a set time of the day
- Take a 2nd reading at the same time the next day
- The difference between the two readings is your daily water consumption

Leak Indicator

– displays a possible leak

- ◆ OFF – indicates no leaks
- ◆ Flashing – indicates water usage for more than 50% of the time during a 24 hour period
- ◆ Continuous ON – indicates water usage at least once every 15 minutes during a 24 hour period. There is most likely a leak in your home



Flow Indicator

– displays direction of water flow

- ◆ ON – water in use
- ◆ OFF – water not in use
- ◆ Flashing – water is running slowly
- ◆ (-) - indicates reverse flow
- ◆ (+) – indicates forward flow

The 9 digit LCD displays your meter reading in cubic meters (m³)

1 m³ = 1,000 L = 220 Imperial gallons

The last 4 digits of the reading are decimal points. In the example above, the meter reading is 26.3987 m³